

## Divider Rail


- It is an extra rail in the middle of the panel
- Creates two sections in the panel so louvers can be operated independently
- To add strength to the panel and enhance panel structure integrity
- Required for panel height over 72"

### Specification

- Standard size: 3"
- Default location: center of the panel unless specify otherwise

### Measurement:

- Window size
  - Measure from the bottom of the window to the center of the divider rail.
- Max Frame to Frame
  - Measure from the bottom of the frame to the center of the divider rail
- Location
  - Per customer. However, divider rail may be adjusted to a lower or higher location, within allowable deviation to ensure strength and aesthetic look of the shutter.
  - Please specify clearly when placing order if the divider rail position should match other shutters. Please also refer to the table to the right for allowable deviation.



### Divider rail allowable deviation

Louver Size	Allowable $\pm$ Deviation
1 $\frac{1}{8}$ "	$\frac{3}{4}$ "
2 $\frac{1}{2}$ "	1"
3 $\frac{1}{2}$ "	1 $\frac{1}{2}$ "
4 $\frac{1}{2}$ "	2"